

VINYL WRAP / PPF / WINDOW TINT / CERAMIC COATING

Give your finish time to settle.

5-7 DAYS

BEFORE WASHING

For wraps and PPF, allow 5-7 days; aim for the full 7 days.

3-5 DAYS

BEFORE LOWERING WINDOWS

After tinting, keep windows fully raised; aim for the full 5 days.

Longer product instructions take priority. Some ceramic coatings need 14 days or longer before washing. Follow your supplied coating instructions; ask ALVION if unsure. Cold or humid conditions can also extend tint curing.

A gentle wash, step by step

1 Start cool and rinse first

Wash in the shade on a cool surface. Rinse away loose dirt with a gentle hose before touching the finish.

2 Use mild soap and clean tools

Choose a pH-neutral automotive shampoo compatible with your finish. Use a clean microfiber mitt and separate wash and rinse buckets. Keep wheel tools separate.

3 Wash gently, from top to bottom

Work one panel at a time with light pressure. Rinse the mitt frequently. Do not scrub dry dirt or let soap dry on the vehicle.

4 Rinse and dry completely

Rinse thoroughly, then dry gently with a clean, plush microfiber towel or suitable air blower. Do not let mineral-rich water dry on the surface.

FINAL WIPE / PPF, VINYL & TINT

Sprayway Foaming Glass Cleaner

ALVION recommends it for a final wipe on compatible PPF, vinyl and tint after curing. Confirm suitability for your installed film and finish with ALVION before use. Follow the can directions; wipe gently with a clean, dry, soft microfiber cloth, then buff with a second dry cloth.



CARE BY SERVICE / WHAT TO AVOID / WHEN TO CONTACT US

Vinyl wrap & chrome delete

Avoid brush car washes, harsh solvents and abrasive polishing. Use gentle hose pressure; never direct a pressure jet at seams or edges. For matte or satin finishes, use finish-safe products and avoid waxes or gloss enhancers that can change the appearance. Do not pull or trim a lifting edge yourself.

Paint protection film (PPF)

Small moisture pockets may appear while the film settles. Do not press, puncture or pick at them. Contact ALVION if they grow, worsen or remain beyond the advised curing period. Self-healing film may reduce fine surface marks; it cannot repair deep cuts, tears or every stone impact.

Window tint

Wait 3-5 days before lowering or cleaning newly tinted windows, unless instructed to wait longer. Use a soft microfiber cloth and a mild, non-ammonia glass cleaner. Avoid blades, abrasive pads and hard objects against the film. Temporary haze can occur during curing; peeling, creases or persistent bubbles need inspection.

Ceramic coating

Follow the coating-specific no-wash and keep-dry periods. Avoid sprinklers and water spotting, especially while curing. Use only compatible maintenance products; do not polish, clay or use strong stain removers without advice. Coatings still need washing and do not make paint scratch-proof or immune to water spots.

Contact us before trying a repair

Send your job number, a short description and clear photos of lifting edges, persistent bubbles, stains or an uneven finish. Do not attempt to cut, heat, peel or rework the affected area. We will advise you and arrange inspection where needed.

After the initial waiting period: wash about every 1-2 weeks, or sooner when dirty. Remove bird droppings, bugs and sap promptly with a compatible cleaner. During curing, contact ALVION for safe spot-cleaning advice.

YOUR WARRANTY

Your signed agreement sets the ALVION warranty period and coverage for each service. This guide does not change those terms. Follow any product-specific care and inspection requirements supplied with your job. Any separate manufacturer warranty follows its own terms.